


# ANIMAL BIN


YOUR BIN IS SUPPLIED ASSEMBLED, LOCKED AND READY TO USE.

1



1. To empty the unit, use the key supplied to open the lock. It will spring out when turned.  
(To lock it again simply push the lock barrel in- it is not necessary to use the key).

2




2. When the lock is unlocked, lift the front edge of the lid upward and then pull towards you to release the lid from the body shell.


"Clean graphics with soapy water only- don't use thinners!"



3



3. The steel liner can now be removed for emptying by lifting out.



locate recess



push to lock in

4. Once the liner has been replaced, reposition the lid using the metal location pin on the rear of the lid and then push the lock back into position to secure the unit.

4