


# JIGSAW BENCH

**YOUR BENCH IS SUPPLIED ASSEMBLED WITH:  
FOUR GROUND FIXING BOLTS**




**TOOLS REQUIRED:**  
17mm Spanner  
10mm Masonry Bit

**1.** Use a 10mm masonry drill bit to drill a hole in the ground through the holes in the jigsaw ends to a depth of 130mm.

**2.** Screw the bolts into the holes through the jigsaw ends using a 17mm spanner.

**3.** Tighten with spanner to secure your Bench to the ground.



*Your Bench is now secure and ready for use!!*