


Installation Instructions



1. Assemble Akadinda frame comprising 2x 'X'-shaped legs and 1x horizontal beam. (See **Assembly Guide**). Cover 8 holes on horizontal beam using **4x30mm caps** (1.1)



2. Locate M8x80mm eye bolts through pre drilled holes using flat washers on both sides of the timber to prevent the fixing pulling into the timber. Secure in place with **M8 nyloc nuts**, cover 4 holes in ends using **4x30mm caps**. (1.3)


3. Place Akadinda in desired location and **mark 4 holes for excavation**.

4. Excavate holes to min depth **150mm** according to required height for intended players. Hole depth guide below.

5. Locate legs in holes and check levels prior to concreting in place. Once happy with location and levels, **fill holes using rapid hardening concrete**. Leave to dry according to manufactures guidelines.




Weight of heaviest part **28kg** (Frame)



Install Instrument with 1.5m free space (from widest point) around it.

Height to centre of notes:
KS0 3-5 500mm Depth 400mm
KS1 5-7 650mm Depth 250mm
KS2 7-11 750mm Depth 150mm
Adult 900mm Surface Mounted

Metric Conversion:	
150mm/ 6"	
250mm/ 10"	
360mm/ 14"	
400mm/ 16"	
500mm/ 20"	
650mm/ 26"	
750mm/ 30"	
900mm/ 35"	
1.5m/ 59"	




48 Kg



Pair Large Red Beaters X2

Ground Fixed

Akadinda
Page 1 of 2



Instrument Components:


-  M10 Wedge Nut X2
-  M10x30 SS Washer X2
-  M8x25 SS Washer X8
-  Eye Straps X2
-  M8 Lock Nut X4
-  10x38mm Secure Screw X4
-  M10x130 Bolt X2
-  5x70mm Screw X4
-  Black Caps X8




Assembly Guide PPAKAD











Tools:

 x1
TX 25 Driver Bit



COMPONENTS LIST:

-  M10 wedge nut X2
-  Black Plastic Cap X8
-  M10x130 Bolt X2
-  M10x30 washer X2
-  M8x25 washer X8
-  5x70 screw X4
-  M8 Nyloc nut X4



Ground Fixed

Akadinda
Page 2 of 2



Instrument Components:

-  M10 Wedge Nut X2
-  M10x30 SS Washer X2
-  M8x25 SS Washer X8
-  Eye Straps X2
-  M8 Lock Nut X4
-  5x40mm Secure Screw X4
-  M10x130 Bolt X2
-  5x70mm Screw X4
-  Black Caps X8



 Pair Large Red Beaters X2

48 Kg