

# Installation Instructions

## Ground Fixed


Cadenza  
Page 1 of 3



### Components:

-  x4  
M8 Nyloc Nut
-  x2  
M6x20 Security Screw
-  x4  
2 Part Cover Cap
-  x1  
M6 Saddle Strap

Metric  
Conversion:  
250mm/ 10"  
400mm/ 15 3/4"  
550mm/ 21  
21/32"  
700mm/ 27 9/16"  
850mm/ 33  
15/32"  
1.5m/ 59"



Weight of heaviest part 7kg (Cadenza)

1. Attach the steel legs to the base of the instrument with the M8 Nyloc Nuts and 2 part security caps. (1.1) (See Assembly Guide)



2. Attach Ground Fixing posts to legs (1.2) (See Ground Fix Post Installation Sheet)

3. Excavate 1 hole for the Steel legs 250mm diameter by 400-550mm deep depending on Key stage, in desired location upon decision from customer.

4. Locate (lower) legs into holes making sure they are vertical and level prior to concreting in place.

5. Once happy with location of the Instrument, fill holes using rapid hardening concrete. Be sure to compact concrete around legs and leave to dry according to manufactures guidelines.

6. Attach the 1 pair of beater to the saddle strap on the leg. (1.3)



Pair Small Red Beaters X1

Ground Fix Components:


-  x2  
M10x200 Bolt
-  x4  
M10 Nut

# Assembly Guide PPCADE



## Ground Fixed

Cadenza  
Page 2 of 3





### Instrument Components:


-  x4  
M8 Nyloc Nut
-  x2  
M6x20 Security Screw
-  x4  
2 Part Cover Cap
-  x1  
Cap
-  x1  
M6 Saddle Strap

Thread Lock Solution  
Required (Not Supplied)










Tools:

-  x1
-  x1



### COMPONENTS LIST:

-  2 Part Cover Cap X4
-  M8 Nyloc nut X4
-  M10 Nut X4
-  M10x200 Threaded Bar X2
-  Saddle Strap X1
-  M6x20 Pin torx X2

 Pair Small Red Beaters X1



### Ground Fix Components:

-  x2
-  x4

14 Kg

# Ground Fix Post Installation

Foundations should not present a hazard. These foundations are recommended as a guide, for more information on foundation details for various surface see Part 7 of BS EN 1176.



400mm min depth

## Ground Fixed

Cadenza  
Page 3 of 3



### Components:



Metric Conversion:  
50mm/ 2"  
250mm/ 10"  
350mm/ 14"  
400mm/ 16"  
450mm/ 18"

