


Installation Instructions




1. Locate Tembos frame onto legs and, and bolt into place using pre drilled holes, **2 bolts per post.**(See Assembly Guide)

2. Attach Surface Fixing posts to legs(1.2) (See Ground Fix Post Installation Sheet)


3. Locate Instrument in desired location and mark holes to fix to desired surface.

4. Fix to Surface using recommended ground anchors not supplied

5. Make sure all fixings are covered and secure using cover caps provided



Weight of heaviest part 52kg (Tembo Frame)



Install Instrument with 1.5m free space (from widest point) around it.

CAUTION: Tembos surface can get hot in direct sunlight, if possible install in shaded areas.

Surface Fixed

Tembos
Page 1 of 3



Components:



x12

M10x100 Security Screw



x24

M10 Flanged Slide Bearing



x2

M6 Eye Bolt

Metric

Conversion:

300mm/ 12"

600mm/ 24"

700mm/ 28"

800mm/ 31"

1.5m/ 59"

2690mm/ 106"



BS EN 1176



Pair Neoprene Paddles X1

Ground Fix Components:



x4



x4



x8

M10x70 Security Screw

M10 Barrel Nut


2 Part Cover Cap


80 Kg

Assembly Guide PPTEMB



Tools:

 x1

 x2

Pin Hex Driver Bit TX 45 Driver Bit


Surface Fixed

Tembos
Page 2 of 3



Main Frame will arrive pre assembled







Thread Lock Solution Required (Not Supplied)




Thread Lock Solution Required (Not Supplied)

CAUTION: Tembos surface can get hot in direct sunlight, if possible install in shaded areas.

COMPONENTS LIST:

-  M6 Eye Bolt X2
-  M10x70 Pin torx X4
-  M10 Barrel Nut Pin torx X4
-  M10x100 Pin torx X12
-  M10 Black Slide Plastic Bearing X12
-  SS Brace Bar X1





Thread Lock Solution Required (Not Supplied)



Pair Neoprene Paddles X1

Ground Fix Components:

-  x4
-  x4
-  x8



70 Kg

Surface Fix Post Installation

Tools:

 x2
TX 45 Driver Bit

Surface Fixed

Tembos
Page 3 of 3



Components:

 x4

M10 Barrel Nut

 x4


M10x70 Security Screw

 x8


2 Part Cover Cap

Thread Lock Solution
Required (Not Supplied)


Metric
Conversion:
300mm/ 12"
600mm/ 24"
700mm/ 28"



1
Locate the Surface fix Plate into the leg of the instrument.



Fix instrument to Surface fix plate using M10 bolt and Barrel Nut and use **thread locking solution** to prevent fixings working loose.



Fix Surface Plate to the ground surface **Ground Anchors Not provided** cover fixings with caps provided

Repeat Parts 1-3 for both legs



BSEN 1176